Boom GIRO Pro

a professional audio device for superior meetings

Quick Guide





Your new GIRO Pro

With 360° omnidrectional microphone pickup and full-duplex HD audio, the Boom GIRO Pro provides a professional conferencing experience for your meetings. Enjoy the convenience of wireless audio via Bluetooth or connect directly to a computer with built-in USB for a plug & play experience. Wireless charging and the included Bluetooth dongle make the GIRO Pro a versatile and convenient solution for better meetings. Simply.



- 1. Omnidirectional microphone
- 5. Volume down

2. Bluetooth key

6. Speaker

3. Volume up

- 7. Bluetooth status
- 4. Microphone mute

What's in the box?

Boom GIRO Pro with USB cable USB donale Carrying case Quick quide

Let's get started

Bluetooth connection

- 1. Plug the Bluetooth dongle into computer.
- 2. Press the power on/off button on your GIRO. Bluetooth light will flash while in connection mode.
- 3. Select Boom GIRO from your computer menu to connect. Enjoy!
- *For cellphone connection, no dongle needed.
- *If Bluetooth indicator turns off (sleep mode) press again to reconnect.
- *Long press the Bluetooth key to disconnect device or switch to USB mode.

Computer connection

- 1. Connect the USB cable to your computer.
- 2. Long press the Bluetooth button for 5 seconds to disconnect if in Bluetooth mode.
- 3. Select Boom GIRO Pro as your speaker and microphone and enjoy!

Cell phone connected via Bluetooth

Answer a call: Short press the power key End a call: Long press the power key

Indicator lights

Green flashing light: speaker is muted Red light: microphone is muted

Orange flashing light: low battery

- *While charging red light is on. Once charging is complete, light turns green.
- *Bluetooth is the default mode. The GIRO Pro enters pairing mode as soon as it's turned on. To switch to USB mode, long press the Bluetooth key to disconnect BT connection.

Need help? Drop us a line or give us a call:

- Phone: 888.534.BOOM (2666)
- Web support: BOOMcollaboration.com/support
- Email: support@BOOMcollaboration.com



Boom GIRO

a professional audio device for superior meetings

Quick Guide





Your new Boom GIRO

With 360° omnidrectional microphone pickup and full-duplex HD audio, the Boom GIRO provides a professional conferencing experience for your meetings. Enjoy the convenience of wireless audio via Bluetooth or connect directly to a computer with built-in USB for a plug & play experience. Better meetings. Simply.



- 1. Omnidirectional microphone
- 2. Bluetooth key

6. Speaker

3. Volume up

7. Bluetooth status

5. Volume down

4. Microphone mute

What's in the box?

Boom GIRO with USB cable Carrying case Quick guide

Let's get started

Bluetooth connection

- Press the power on/off button on your GIRO.
 Bluetooth light will flash while in connection mode.
- 2. Select Boom GIRO from your computer/cell phone menu to connect. Enjoy!
- *If Bluetooth indicator turns off (sleep mode) press again to reconnect.
- *Long press the Bluetooth key to disconnect device or switch to USB mode.

Computer connection

- 1. Connect the USB cable to your computer.
- 2. Long press the Bluetooth button for 5 seconds to disconnect if in Bluetooth mode.
- 3. Select Boom GIRO as your speaker and microphone and enjoy!

Cell phone connected via Bluetooth

Answer a call: Short press the power key End a call: Long press the power key

Indicator lights

Green flashing light: speaker is muted Red light: microphone is muted Orange flashing light: low battery

- *While charging red light is on. Once charging is complete, light turns green.
- *Bluetooth is the default mode. The GIRO enters pairing mode as soon as it's turned on. To switch to USB mode, long press the Bluetooth key to disconnect BT connection.

Need help? Drop us a line or give us a call:

- Phone: 888.534.BOOM (2666)
- Web support:
 BOOMcollaboration.com/support
- Email: support@BOOMcollaboration.com

